



Lower the unit into the fuel inlet.

Rotate the installation ring with the three tabs so that it catches just like the fuel cap.

Customer feedback: Add something like PermaShield to the cork gasket before installing



Tighten the snap-off screws equally. Be careful to do them in sequence.

Turn the first screw one turn, then the second, then the third and so on, until they are almost tight.

When you're ready to finish, continue to tighten the screws and the head will snap off.

