



DIESELKeeper™



Remove the fuel cap and stay bar.

Remove any existing anti-siphon device.

Insert the Robond anti-siphon device into the fuel inlet.



With a block of wood, use a mallet to tap the anti-siphon device into place.

Installation is permanent!

Remove the stay bar from the chain.

Attach the new clip to the chain.



Attach the new clip
to the inside
of the
anti-siphon device.